



We have our video install guides on our website and on youtube.com. Also feel free to call or email us if you have any questions
1-855-457-5683
info@lovethedrive.com

Camaro 2011 to 2015

Love The Drive Wind Deflector

Install Guide

- * You can raise and lower your convertible top with the wind deflector installed.
- * The wind deflector will fit in the trunk when not in use.

Start by lowering your top and moving the front seats all the way forward.

Your Camaro is designed to be fitted with a wind deflector. There is a hole on each side of the rear trim panel. This is where the front barrel bolts fit into.



There is also a slot in each side of the rear trim panel beside the back seat. This is where the rear brackets slide into.



Standing on the drivers side. Flip out the rear bracket on the passenger end. This is what will slide into the slot beside the back seat on the passenger side.



Then extend the barrel bolt on the passenger side as well. And then turn the handle down to lock it in place.



Now lower the wind deflector into the back seat area so the rear bracket goes into the slot beside the rear seat.



Then guide the wind deflector so the extended barrel bolt goes into the hole on the passenger side trim panel.



Next, flip out the rear bracket on your end and slide it into the rear slot. Now line up the barrel bolt to the hole in the trim panel, extend the bolt and turn the handle down to lock it into place.



You can now raise the top panel of the wind deflector and you are ready to **Love The Drive.**

