



We have our video install guides on our website and on youtube.com also feel free to call or email us if you have any questions 604-628-7529 info@lovethedrive.com

Thunderbird 2002 to 2005

Love The Drive Wind Deflector

Install Guide

Start by lowering your top and moving your seats forward in your Thunderbird.

Your wind deflector will sit above the cover for your seat belts. The strap on the passenger side attaches to the silver anchor at the bottom back of the passenger seat.



Your wind deflector attaches to your T-bird using two metal brackets and one strap. One bracket on each side attaches to the trim panel behind your seats. The bracket has a felt mat on the bottom so it will not scratch the top of your trim panel.




There are two thumb screws that attach the bracket to the trim panel. Start by loosening the thumb screws so there is enough space to slide the brackets onto the trim panel.



Remove one of the brackets by loosening the large single thumb screw on one end. Then slide the remaining bracket onto the trim panel, close to the middle of the seat belt cover.




Next slide the other bracket onto the trim panel. Again about in the middle of the seat belt cover, so the wind deflector panel can be reattached to the bracket.



Next tighten the two thumb screws on each side tightly. You might consider using a small pair of pliers. This is a very tight space.



Then attach the large thumb screws on each end to the hole in the wind deflector to the bracket. Now tighten all the small thumb screws.



The final step is to attach the snap hook strap to the metal anchor at the bottom of the passenger seat back.



Your wind deflector can be left in place while raising and lowering the top. It can also be quickly removed and put in the storage bag to store in the trunk.