



We have our video install guides on our website and on youtube.com also feel free to call or email us if you have any questions 604-628-7529 information@lovethedrive.com

# Mercedes 380SL, 450SL, 560SL 1972 to 1989 (107) Love The Drive Wind Deflector Install Guide

Start by putting your top down. Your new Love The Drive wind deflector attaches to the convertible top lid.



**Step 1:** Start by placing the wind deflector into the area behind the front seats, on top of the lid. Make sure that it is sitting straight.



The wind deflector is held in place by two latches on each side and two brackets in the back.



**Step 2:** Make sure that the back brackets are touching the back of the lid. The brackets and latches are coated in a soft plastic so they will not mark or scratch the leather.



The front latches are located on either side of the wind deflector and latch onto the bottom of the convertible top lid.



**Step 3:** Make sure that the latch is under the lid and then push up. It is recommended that you hook the latches at the same time.



If you would like to remove your wind deflector we recommend that it be stored in the bag provided. It can then be placed in the trunk.



**Step 4:** Lift the wind deflector up and you are now ready to LOVE THE DRIVE!



**If you have any questions or comments please call 604-628-7529 or email [information@lovethedrive.com](mailto:information@lovethedrive.com) [www.lovethedrive.com](http://www.lovethedrive.com)**