



We have our video install guides on our website and on youtube.com. Also feel free to call or email us if you have any questions
1-855-457-5683
info@lovethedrive.com

Camaro & Firebird 1993 to 2002

Love The Drive Wind Deflector

Install Guide

- * You can raise and lower your convertible top with the wind deflector installed.
- * The wind deflector will fit in the trunk when not in use.

Start by lowering your top and moving the front seats all the way forward.

Your Camaro or Firebird wind deflector fits your convertible without modifications.



The wind deflector attaches to your convertible and is held in place using 4 brackets and 4 straps





Lower the wind deflector into the back seat. The front brackets sit just behind your seatbelt compartment.

The rear bracket can be adjusted to align with the trim panel.



There are two straps on each side of the wind deflector. They come with quick release buckles so the wind deflector can be easily removed if necessary.

The two straps are attached to the bottom of the trim panel. The straps are tightened to hold the wind deflector in place.



The front strap has a silver hook and attaches to the bottom of the trim panel beside the rear seat. Pull the strap down to tighten the front straps.



The rear straps are attached to the trim panel beside your rear seat. Pull the bottom panel of the rear seat back and attach the black hook into the cut out of the trim panel. Then pull the strap to secure the wind deflector.



You can now raise the top panel of the wind deflector and you are ready to **Love The Drive.**

