



We have our video install guides on our website and on youtube.com.

Also feel free to call or email us if you have any questions about how to install your wind deflector

1-855-457-5683

information@lovethedrive.com

VW Beetle from 2012 to 2019 Love The Drive Wind Deflector Install Guide

- * You can raise and lower your convertible top with the wind deflector installed.
- * Start by lowering your top and moving the front seats all the way forward.

Your VW Beetle was designed for a wind deflector to be installed. There are four holes in your trim panel. Two holes on each side.



Your wind deflector has four bolts that slide into these holes. Two in the front and two in the rear.



Start by lowering your wind deflector into the rear seat area.



Slide Front bolts into the front holes and then turn the handle down (towards the floor) to lock the handle.



Hold the wind deflector so the barrel bolt is aligned with the hole on the side trim panel.



Turn the handle down (towards the floor) to lock the handle.



The Wind Deflector will NOT fit in the trunk of your Beetle. It can fit behind the rear seat.



The Wind Deflector will NOT fit in the trunk of your Beetle. It can be slide thru the trunk with the seats folded down.

