



We have our video install guides on our website and on youtube.com Also feel free to call or email us if you have any questions 1-855-457-5683 information@lovethedrive.com

Mini Convertible from 2004 to 2015 Love The Drive Wind Deflector Install Guide

- * You can raise and lower your convertible top with the wind deflector installed.
- * Start by lowering your top and moving the front seats all the way forward.
- * The Wind Deflector DOES NOT Fit in the Trunk with the Top DOWN

Your Mini is designed to be fitted with a wind deflector. There are two holes on each side of the rear trim panel. The front and rear barrel bolts fit into these holes.



Start by extending the front and rear barrel bolts on one side of the wind deflector. Turn the handles so they will face down, this locks the bolts into place. These bolts will slide into the holes on the opposite side of the car from which you are standing.



Next, lower the wind deflector into the back seat area and insert the front bolt into the hole into the trim panel and then insert the rear bolt.



Now lower the wind deflector into the back seat area so the front barrel bolt is in line with the front hole. Slide the bolt forward into the hole and turn the handle down to lock the bolt.



Next, reach back and slide the back bolt into the rear hole and turn the handle down to lock the barrel bolt



When you are finished please double check that all four handles are turned downwards so the barrel bolts are in the locked position.



Your wind deflector will not fit in your Trunk. Your wind deflector will fit in the Passageway between the trunk and backseat. One side of the backseat must be lowered flat and the wind deflector can be passed thru.



Your wind deflector can be left in place with your convertible top up or down. Many customer never remove their wind deflector

