



We have our video install guides on our website and on youtube.com. Also feel free to call or email us if you have any questions
1-855-457-5683
information@lovethedrive.com

Audi A5 2016 to 2023

Love The Drive Wind Deflector

Install Guide

- * You can raise and lower your convertible top with the wind deflector installed.
- * The wind deflector will NOT fit in the trunk without the seats down.

Start by lowering your top and moving the front seats all the way forward.

Your Audi A5 is designed to be fitted with a wind deflector. There are two holes on each side of the rear trim panel. The front and rear barrel bolts fit into these holes.



Start by extending both barrel bolts on one end of the wind deflector. Turn the handles so they are facing down, when in the car. This locks the bolts into place. These bolts will slide into the holes on the opposite side of the car from which you are standing.



Lower the wind deflector into the back seat area and insert the front bolt into the hole and then insert the rear bolt.




Now, lower your end into the back seat area so the front barrel bolt is in line with the front hole. Slide the bolt forward into the hole and turn the handle down to lock the bolt.



Next, reach back and slide the back bolt into the rear hole and turn the handle down to lock the barrel bolt



When you are finished please double check that all four handles are turned downwards so the barrel bolts are in the locked position.



When not in use, your wind deflector can be stored in the pass thru from the trunk into the backseat. Both rear seats will need to be folded down. Free storage bag is included.



Another option. Your wind deflector can be placed in the rear seat area.

Please contact us if you have any other questions information@lovethedrive.com

