

*LUMINII RESERVES THE RIGHTS TO CHANGE SPECIFICATION & INSTRUCTION WITHOUT NOTICE

LineLED 24V - Installation Instructions

Models LLRGB42-XX

Please read all instructions prior to installation and keep for future reference!

- 1. PRODUCT SHOULD BE INSTALLED BY A QUALIFIED ELECTRICIAN 2. ENSURE POWER IS OFF AT FUSE BOX PRIOR TO INSTALLATION TO PREVENT
- ELECTRICAL SHOCK
- 3. USE ONLY WITH CLASS 2 POWER UNIT

- 4. SUITABLE FOR DAMP LOCATIONS
 - 5. FOR UNDER CABINET OR SHELF MOUNT
 - 6. CONFORMS TO UL STD 2108. CERTIFIED TO CSA
 - STD C22.2 NO.250.0.

7777 Merrimac Ave Niles, IL 60714 T 224.333.6033 F 224.757.7557 info@luminii.com www.luminii.com

REVO.5

10082024

2/2

6 6.1 Follow RGBW controller and receiver instructions for all wiring connections. solder Refer to diagram for needed components. pads wire leads LLRGB42 wireless or wired **RGBW** controller 5.1 If required for installation, cut the LLRGB42 strip between two rows of solder pads. Always cut LLRGB42 from end without connector / wire leads. LLRGB42 24V PSV receiver / decoder power supply LLRGB42 repeater **OPTIONAL**

Power Supply Wiring Diagram

Note: Prior to installation all 24VDC wires must be present near fixture. Refer to the power supply installation instructions for additional information.



RGB/RGBW Wiring Diagram PDF