TW-DMX Controller - Installation Instructions


Models TW-DMX

Please read all instructions prior to installation and keep for future reference!

- Product to be installed by a qualified electrician.
 Prior to installation ensure power is off at fuse box to prevent electrical shock.
 All DMX products to be installed per DMX512 Standard.









contractor) to connect controller properly.


Connect the white (neutral) & black (hot) power supply wires to the white & black power wires (120 - 240VAC).




2.1 Carefully insert a flat screw driver into the controller housing tab and slightly pull up until controller face comes off.



Loosen the screws on the back of the controller housing and make all the proper wiring and then re-tighten screws. Refer to the wiring diagram on page 2 for additional information.



4.1 Align the controller housing to the junction box and secure using the two screws.



5.1 Align the back of the controller face to the controller housing pins and snap in to secure.

TW-DMX Controller - Installation Instructions

Models TW-DMX


Please read all instructions prior to installation and keep for future reference!

- Product to be installed by a qualified electrician.
 Prior to installation ensure power is off at fuse box to prevent electrical shock.
 All DMX products to be installed per DMX512 Standard.

Page 2 of 3



Wiring Diagram



TW-DMX Controller - Installation Instructions

Models TW-DMX

Please read all instructions prior to installation and keep for future reference!


- 1. Product to be installed by a qualified electrician.
- Prior to installation ensure power is off at fuse box to prevent electrical shock.
 All DMX products to be installed per DMX512 Standard.

Page 3 of 3



Controller Buttons

Description of buttons



Operations

1. Set DMX Address

Set all DMX Decoder as DMX Address 001

2. Save color

- 1)Touch color wheel to choose the color
- 2)Long press a target number over 3 seconds(light flashing means successfully saved, saving 1-6 colors will cover the original colors)

3. Default setting colors

Long press (b) to default settings as following colors.

- (1) 100% Warm white (2) 50% warm white +50% cool white
- (4) 50%Natural white +50% cool white (3) 100% Natural white
- (5) 100% Cool white (6) 50% Cool white +50% warm white