


Installation Guide


SADIE 24", 46", 69", 90"

SLIVER 24", 46", 69", 90"


PLATO 24", 46", 69", 90"



SADIE



SLIVER




PLATO



alva®

1. INSTALL MOUNTING BRACKET ON JUNCTION BOX.



2. **FOR 24" SCONCES:** INSTALL AC DIRECT MODULE TO THE MOUNTING PLATE RUNNING THE WIRES THROUGH THE HOLE AT THE TOP OF THE PLATE.

MAKE ELECTRICAL CONNECTION IN THE JUNCTION BOX (SEE FIGURE 1). JUNCTION BOX CAN BE LOCATED ANYWHERE BEHIND THE FIXTURE (SEE FIGURE 2).

THEN, SCREW THE MODULE AND MOUNTING PLATE TO THE BRACKET CONNECTED TO THE JUNCTION BOX WITH THE 4 SCREWS PROVIDED.




FIGURE 1:
JUNCTION BOX INLINE WITH MOUNTING PLATE






FIGURE 2:
JUNCTION BOX OFFSET FROM MOUNTING PLATE

3. APPLY A BEAD OF SILICON AROUND THE MODULE MOUNTING PLATE. THE BEAD SHOULD TOUCH THE SIDE OF THE MOUNTING PLATE AND THE WALL.

BEAD OF SILICON
AROUND THE MODULE
MOUNTING PLATE



4. SLIDE OVER THE PLASTIC SHADE. THEN SCREW THE 2 SEALING PAN HEAD SCREW ON THE TOP AND BOTTOM. APPLY SILICONE TO HOLES AS NEEDED.



CONTINUE FOR DIAGRAM OF 46", 69", 90" SCONCE INSTALLATION →

2. **FOR 46", 69", 90" SCONCES:** INSTALL AC DIRECT MODULE TO THE MOUNTING PLATE RUNNING THE WIRES THROUGH THE HOLE AT THE TOP OF THE PLATE. MAKE ELECTRICAL CONNECTION IN THE JUNCTION BOX (SEE FIGURE 1). JUNCTION BOX CAN BE LOCATED ANYWHERE BEHIND THE FIXTURE (SEE FIGURE 2). THEN, SCREW THE MODULE AND MOUNTING PLATE TO THE BRACKET CONNECTED TO THE JUNCTION BOX WITH THE 4 SCREWS PROVIDED.




FIGURE 1:
JUNCTION BOX INLINE WITH MOUNTING PLATE






FIGURE 2:
JUNCTION BOX OFFSET FROM MOUNTING PLATE

3. APPLY A BEAD OF SILICON AROUND THE MODULE MOUNTING PLATE. THE BEAD SHOULD TOUCH THE SIDE OF THE MOUNTING PLATE AND THE WALL:



4. SLIDE OVER THE PLASTIC SHADE. THEN SCREW THE 2 SEALING PAN HEAD SCREW ON THE TOP AND BOTTOM. APPLY SILICONE TO HOLES AS NEEDED:



alva®